


SC SCA FCAT Pre-Polished Connector: Instructions










1. Assembly Components









2. Assembly Tools





- Step 1
 - A. Insert the boot on the 900um tight buffer fibre.
 - B. Strip off the buffer so that there is 5cm or more exposed.







- Step 2
 - A. Mark with a pen on the 250um coating, 18mm from the 900um buffer.
 - B. Strip off the 250um coating from the end of the fibre, leaving 18mm of 900um buffer.
 - C. Wipe clean with alcohol wipe












- Step 3
 - A. Cleave the bare fibre to be 10mm









- Step 4
 - A. Insert the fibre in the connector body through the fibre guide so it has a slight bend to maintain pressure and keep it in position







- Step 5
 - A. Remove the Black Clip






- Step 6
 - A. Press the centre of the yellow button while maintaining enough pressure on the fibre for it to bend slightly.
 - B. Release the pressure, pull the cable back enough so it can be inserted into the guide (ie slot)








- Step 7
 - A. Tighten the boot.
 - B. Insert into coloured housing.








MSF SC SCA FCAT – Disassembly Instructions

1. Disassembly Procedure

- Step 1
 - A. With the dust cap on, hold the coloured housing as shown below and push down onto a hard surface.
 - B. Unscrew the boot.







MSF SC SCA FCAT – Disassembly Instructions

1. Disassembly Procedure

- Step 2
 - A. Press the black clip back onto the connector body.
 - B. Remove the fibre from the connector.



